

**BEDIENUNGSANLEITUNG  
MIYOTA UHRWERK KALIBER GP00**

---

**MANUAL FOR MIYOTA MOVEMENT  
CAL. GP00**



## BEDIENUNGSANLEITUNG FUER MIYOTA UHRWERK KALIBER GP00

» BATTERIE: SR920SW

FUNKTION: RETROGRADE 24-STUNDENANZEIGE UND BIG DATE


A) DISPLAYS

B) DIE ZEIT EINSTELLEN

C) DAS DATUM EINSTELLEN

D) EINSTELLEN DER 24-STUNDENANZEIGE

## A) DISPLAYS



## **B) DIE ZEIT EINSTELLEN**

- ▶ ZIEHEN SIE DIE KRONE IN DIE ZWEITE POSITION HERAUS.
- ▶ DREHEN SIE DIE KRONE UM DEN STUNDEN- UND MINUTENZEIGER EINZUSTELLEN.
- ▶ WENN SIE DIE KRONE IN DIE NORMALSTELLUNG ZURUECK DRUECKEN, BEGINNT DER SEKUNDENZEIGER ZU LAUFEN.

## C) DAS DATUM EINSTELLEN

- › ZIEHEN SIE KRONE IN DIE ERSTE POSITION HERAUS.
- › DREHEN SIE DIE KRONE IM UHRZEIGERSINN UM DAS DATUM EINZUSTELLEN.

**HINWEIS:** WENN DAS DATUM ZWISCHEN 21:00 UHR UND 02:00 UHR UMGESTELLT WIRD, KOENNTE ES SEIN, DASS DAS DATUM AM NAECHSTEN TAG NICHT KORREKT ANGEZEIGT WIRD.

- › SOBALD DAS DATUM UMGESTELLT IST, DRUECKEN SIE DIE KRONE IN DIE NORMALPOSITION ZURUECK.

## **D) EINSTELLEN DER 24-STUNDENANZEIGE**

- 】 ZIEHEN SIE DIE KRONE IN DIE ERSTE POSITION HERAUS.**
- 】 DREHEN SIE DIE KRONE GEGEN DEN UHRZEIGERSINN UM DIE 24-STUNDENANZEIGE EINSTELLEN.**
- 】 SOBALD DIE 24-STUNDENANZEIGE UMGESTELLT IST, DRUECKEN SIE DIE KRONE IN DIE NORMALPOSITION ZURUECK.**

## » ENTSORGUNGSHINWEIS ZU BATTERIEN UND ALTGERÄTEN

VERBRAUCHTE BATTERIEN UND ALTGERÄTE DÜRFEN NICHT ÜBER DEN HAUSMÜLL ENTSORGT WERDEN. BITTE GEBEN SIE ALTE BATTERIEN UND ALTGERÄTE – WIE GESETZLICH VORGESCHRIEBEN, UNENTGELTLICH BEI DEN ENTSPRECHENDEN ÖFFENTLICHEN SAMMELSTELLEN ODER IM HANDEL AB. DAMIT IST GEWÄHRLEISTET, DASS EINE FACHGERECHTE ENTSORGUNG STATTFINDET UND NEGATIVE AUSWIRKUNGEN AUF DIE UMWELT VERMIEDEN WERDEN.

BATTERIEKENNZEICHNUNGEN:

PB (= BLEI), HG (= QUECKSILBER), CD (= CADMIUM)



WEEE-REG.-NR.: DE45404959





## INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT CALIBER NO. GP00

▶ BATTERY: SR920SW

FUNCTION: RETROGRADE DUAL TIME AND BIG DATE


A) DISPLAYS

B) SETTING THE TIME

C) SETTING THE DATE

D) SETTING THE 2<sup>ND</sup> TIME (24 HOURS)

## A) DISPLAYS



## **B) SETTING THE TIME**

- ▶ PULL THE CROWN OUT TO THE 2<sup>ND</sup> POSITION.
- ▶ TURN THE CROWN TO SET HOUR AND MINUTE HANDS.
- ▶ WHEN THE CROWN IS PUSHED BACK TO THE NORMAL POSITION, SECOND HAND BEGINS TO RUN.

### **C) SETTING THE DATE**

- ▶ PULL THE CROWN OUT TO THE 1<sup>ST</sup> POSITION.
- ▶ TURN THE CROWN CLOCKWISE TO SET THE DATE.

**NOTE:** IF THE DATE IS SET BETWEEN THE HOURS OF AROUND 09:00 PM AND 02:00 AM, THE DATE MAY NOT CHANGE ON THE FOLLOWING DAY.

- ▶ AFTER THE DATE HAS BEEN SET, PUSH THE CROWN BACK TO THE NORMAL POSITION.

## **D) SETTING THE 2<sup>ND</sup> TIME (24HOURS)**

- ▶ PULL THE CROWN OUT TO THE 1<sup>ST</sup> POSITION.
- ▶ TURN THE CROWN COUNTER-CLOCKWISE TO SET THE 2<sup>ND</sup> TIME (24HOURS).
- ▶ AFTER THE 2<sup>ND</sup> TIME (24HOURS) HAS BEEN SET, PUSH THE CROWN BACK TO THE NORMAL POSITION.

**▶ IMPORTANT: PLEASE ENSURE THAT OLD BATTERIES AND ELECTRONIC DEVICES ARE SAFELY DISPOSED OF IN COMPLIANCE WITH LEGAL REGULATIONS.**

**OLD BATTERIES AND ELECTRONIC DEVICES MUST NOT BE THROWN AWAY TOGETHER WITH HOUSEHOLD TRASH. CONSUMERS ARE LEGALLY OBLIGED TO DISPOSE OF BATTERIES OF ALL KINDS BY RETURNING THEM TO LOCAL COLLECTION POINTS. THIS ENSURES THAT BATTERIES AND ELECTRONIC DEVICES CAN BE DISPOSED OF PROPERLY WITHOUT CAUSING ANY HARM TO THE ENVIRONMENT.**

**IDENTIFICATION:**

**CD (= CADMIUM), HG (= MERCURY), PB (= LEAD)**



**WEEE-REG.-NR.: DE45404959**

**Aviano Jewels GmbH**  
**Gutenbergstraße 2 – 4**  
**85737 Ismaning**  
**Germany**